

699PLUS CONTROLLER CONNECTIONS


| Screw Terminal | Meaning |
|----------------|------------------------------------|
| 1 | GND (DC POWER SUPPLY) |
| 2 | + 24 V (DC POWER SUPPLY) |
| 3 | EARTH connection |
| 4 | CONTACT I/O 2 (Display Zeroing) |
| 5 | CONTACT I/O 1 (Chain compensation) |
| 6 | I/O CONTACT's common reference |
| 7 | Relay 3 - Normally Open contact |
| 8 | Relay 3 - Normally Closed contact |
| 9 | Relay 3 Common contact |
| 10 | Relay 2 - Normally Open contact |
| 11 | Relay 2 - Normally Closed contact |
| 12 | Relay 2 Common contact |
| 13 | Relay 1 - Normally Open contact |
| 14 | Relay 1 - Normally Closed contact |
| 15 | Relay 1 Common contact |
| 16 | + power supply to transducer |
| 17 | - power supply to transducer |
| 18 | + signal form transducer |
| 19 | - signal from transducer |
| 23 | AGND (Analog output) |
| 24 | Analog Output |

Ground to earth the 699 electronics and respect all the relevant safety and electrical regulations.

Once performed all the needed electrical connections feed power supply and wait 15 minutes, before calibrating. **Measurement changes are displayed in tens of the used engineering units.**

POWER SUPPLY = 24 Vdc

699PLUS CONTROLLER



- QTY 1 699Plus weight controller
- QTY 2 Fixing screws, type M4 x 12 UNI 7687
- QTY 2 Nuts, type M4

PUSHBUTTONS AND THEIR ACTION for 699Plus programming

Use ▲ or ▼ to view available parameters.

Use **E** to view and modify existing numeric parameter or to confirm changes to parameter. 699Plus indicates that new parameter has been accepted by showing, briefly, **MEMO** and then displaying again the parameter's name.

Use **C** to:

- abort changes to numeric parameter, maintaining the existing value
- end calibration – SAVE changed parameters - and start load measurement

To modify numeric parameters, use ▲ to increase or ▼ to decrease value of one unit.

▲+ **E** increase value of 10 and then 100 units while ▼+ **C** decreases of 10 and then 100 units.

699PLUS PROGRAMMING

MANU PROCEDURE

Calibration of the installed load measuring system must be done when lift's cabin is at the lowest floor of the plant, or at the most frequently used.

Measurement changes are displayed in tens of the used engineering units.

Once system has been installed, enter programming procedure by:

- power the 699Plus keeping pressed **▲+C** buttons (min 5 sec.), OR
- press **▲+C** buttons (min 5 sec.) while pressing RESET

Display will show **MANU** to confirm procedure activation.

1 - TARE

- WITH EMPTY CABIN, send the lift to the lowest floor
- Jump slightly on top or inside the cabin
- Use **▲** or **▼** to select **TARE**
- Press **E** to start count down (60 sec; display shows from **T-60** to **T-0**), step off from the lift and wait until the countdown ends
- Tare measurement is completed after **MEMO** is displayed and **TARE** is shown again.

2 - HI

- Place known load in the cabin (from 50% to 80 % of lift's rated capacity)
- Use **▲** or **▼** to select **HI** and press **E**
- Enter the weight value in engineering units (Kg/lb) and press **E** to start count down (60 sec, from **T-60** to **T-0**), step off from the lift and wait until the countdown ends
- If process is successful, **MEMO** is displayed and **HI** is shown again

3 – FSCA: lift's rated load, in engineering unit. *Default value = 0*

- Use **▲** or **▼** to select **HI** and press **E**
- Modify **FSCA** load and press **E**

4 – LEV1: Full Load (RELAY 1) as percentage of the rated load (modifiable value)

Default value = 80 % FSCA

- Use **▲** or **▼** to select **LEV1** and press **E**
- Modify **LEV1** value and press **E**

5 – LEV2: Overload (RELAY 2) as percentage of the rated load (modifiable value)

Default value = 110 % FSCA

- Use **▲** or **▼** to select **LEV2** and press **E**
- Modify **LEV2** value and press **E**

6 – LEV3: Presence (RELAY 3) as percentage of the rated load (modifiable value)

Default value = 5 % FSCA

- Use **▲** or **▼** to select **LEV3** and press **E**
- Modify **LEV3** value and press **E**


7 – CHNC: Compensation chain enabling signal (contact 5 and 6, continuous +12/24Vac/dc signal when doors are closed). Inactive (default) if **CHNC=0**; active if **CHNC=1**.

- Use **▲** or **▼** to select **CHNC** and press **E**
- Select 0 or 1 and press **E**

8 – press C to end calibration and save parameters


ERROR CODES

| Code | Meaning |
|--------------|--|
| ER.01 | <i>Negative Load:</i> ER01 indication is displayed alternatively to the measured load (the minus sign is displayed only up to three numbers, i.e. -999). <i>Check connections and recalibrate.</i> |
| ER.22 | <i>Conversion slope not correct: too high signal from 942 Strain Link</i> (fix 942 to a more rigid part of the lift frame or substitute it). <i>Verify that HI value is entered with the right resolution</i> (use weight at least 80% FSCA). |
| ER.23 | HI value is too low (in engineering units). HI-Tare must be > 10 |
| ER.24 | Calibration Load is too low. Increase load. |
| ER.26 | TARE and HI values identical, in engineering units. |
| ER.28 | <i>Overrange/Underrange:</i> ER.28 is displayed alternatively to measured load. Verify that sensor mechanical installation is OK and corresponding to Factory indications. In case perform again Sensor Installation. Calibrate again the 699Plus after the modifications. |
| ER.30 | <i>C button</i> pressed for more than 3 seconds, when 699Plus controller is in calibration mode. |




A) 699 Plus electronics Analog Output setting (Optional)

Making reference to the 699 customization procedures, parameter setting for analog output signal must be done considering the following flowchart:



Note: the analog output circuit provides an analog output signal for all operative modes. The firmware version is to be at least 1.17 or higher. To obtain a reversed 10V to 0V output, calibrate DACL with high engineering units (measuring range) while on DACH enter lower ones. Analog output signal connection is as per attached connection scheme.

B) Analog output connection scheme for code 00.03.010.0010:




Analog Signal A1 = from 0 to 10V

AGND = analog signal GND

NOTE:

In order to obtain the best accuracy from the instrument's analog output signal, use 3 wires to connect the lift's Inverter to 699Plus analog output.

WARNING: POWER SUPPLY MINUS, provided to 699Plus instrument is NOT the AGND analog output ground. Power 699Plus with a floating power supply.



Note: 0 to 10V output signal is available for 699 Plus A1 electronics (code 00.03.010.0010).

Document history

| Rev. | Date | Description | Firmware | Hardware | Writer | Check |
|------|--------|-------------|-----------|----------|----------|-----------|
| 0 | 010618 | First issue | 699Bv1.00 | 699V1r0 | S.Piardi | D.Disanto |